

Foucault Pendulum Electronics Kit.

D99_Errata.

www.foucaultpendulum.nl

Document version	2025-11-02
Relates to PCB version	
Related Documents	

On the Receivers PCB the traces for TP5, TP6, TP11, TP12, TP17 and TP18 are missing. They are on the schema but not on the board.

The remedy: Take 6 pieces of cutoff wires from resistors, bend a eyelet of a few mm on one side, put it in the TP-hole, and solder it on the bottom side to the cathode of the adjacent diode. The eyelet can be used to hook an oscilloscope probe for testing.